



**GALAXY STONE**  
EPOXY STONE FLOORING

# Instruction for applying Galaxy Stone sealer

## IMPORTANT

- \* Pressure wash stone prior to resealing.\*
- \*Stone must be completely dry. (2-3 days)\*
- \*Must be applied on a WARM/DRY day. The product is porous, although the surface may be dry the subsurface is not dry. (2-3 days since last contact with water)\*
- \*No precipitation 24 hours after application\*
- \*Mixture will begin to cure after 15 minutes.\*
- \*Latex gloves RECOMMENDED\*
- \*Let cure for 24 hours before walking or placing furniture.\*

## Mixing Entire Reseal Kit:

1. Combine 1 gallon jug (Part "A") and metal can (Zylene) into 5 gallon bucket.
2. Stir WELL with paint stick. (3-4 minutes)
3. Add ½ gallon jug (Part "B") to mixture.
4. Mix THOROUGHLY. Making sure to scrape sides and bottom to ensure an even mix. (3-4 minutes)
5. Apply mixture onto stone with paint roller and/or paintbrush.
6. Broadcast non-skid immediately after application. (Optional)

## Mixing ½ Kit:

1. Combine ½ of the 1 gallon jug (Part "A") and ½ metal can (Zylene) into 5 gallon bucket.
2. Stir WELL with paint stick. (3-4 minutes)
3. Add ½ of the ½ gallon jug (Part "B") to mixture.
4. REPEAT ABOVE STEPS 4-6.

## Materials Needed:

1. 3/8" or 1/2" Nap Rollers
2. Roller Frames or Extension Pool
3. Paint Brushes

**Please CONTACT if unsure on any part of the process:**